

HAMPTON BAY

ITEM #1001 074 624 MODEL # FCS60492-ST

Brookside 3-piece Steel Sling Dining Set Operations Guide

Important Safety Instructions

SAVE THESE INSTRUCTIONS



WARNING: This set was made for the explicit purpose of providing outdoor functions and is not to be used as a toy.

This product is intended for normal outdoor use; however, the manufacturer recommends storing and / or covering this set when any formidable / severe weather is approaching.



WARNING: Do not locate this product near open flames. Do not use this product as a support. Do not shake, lean or climb on the product. Children under the age of 10, near the product, should be supervised by a competent adult at all times. This product is NOT intended for commercial use and will void the warranty.

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

- Close supervision is necessary when this product is used by or near children, or disabled persons, if applicable.
- Use this product only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
- 3. Do not move the chairs while the chairs are occupied. Failure to obey this caution could result in injury.
- 4. Do not rock in the chair as you may fall and cause serious injury.
- 5. Please keep children out of the assembly area before assembly.



WARNING: Weight limit for the chairs is 225 lbs (102.05 kg)for each seat.



WARNING: Do not place heavy objects on the chair.



WARNING: Do not place heavy objects on the table top.



CAUTION: When not in use, secure the product in a cool and covered location.



CAUTION: Do not locate the product near any heat source.

Warranty

2 YEAR FRAME AND 2 YEAR FABRIC LIMITED WARRANTY

WHAT IS COVERED

We warrant the frames to be free of manufacturing defects to the original purchaser for two years, and a two year limited warranty for the fabric.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center.

This warranty does not cover commercial use, hardware, acts of nature, fire, freezing, and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

For questions or concerns about this product, contact the Customer Service Team 8 a.m. - 7 p.m., EST, Monday through Friday 9 a.m. - 6 p.m., EST, Saturday at 1-855-HD-HAMPTON or visit www.HomeDepot.ca.

Operation


1 Opening the chairs

Slide the seat outward until the chairs fully extend outward.



2 Closing the chairs

Gently push the seat backward.



For certification use only

Factory ID # FCS60492-ST

Care and Cleaning

- □ For best results, clean the frame with a damp cloth, and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- □ Do not clean with abrasive materials, bleach or solvents.
- Store in a dry, sheltered place when not in use.
- □ Keep away from fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.