
# HAMPTON BAY

## **USE AND CARE GUIDE**

### CRESTRIDGE STEEL SLING PADDED CHAISE LOUNGE, 2PK



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. - 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-855-HD-HAMPTON

**HOMEDEPOT.CA** 

#### THANK YOU

### **Table of Contents**

Table of Contents	Pre-Assembly	3
mportant Safety Instructions2	Planning Assembly	3
Save These Instructions2	Hardware Included	4
Read All Instructions before Use	Package Contents	4
Warranty	Assembly	5
What is covered	Care and Cleaning	
What is not covered	outo una otouning treatment treatment and tr	9

### **Important Safety Instructions**

#### SAVE THESE INSTRUCTIONS



**WARNING:** THIS CHAISE WAS MADE FOR THE EXPLICIT PURPOSE OF PROVIDING OUTDOOR FUNCTIONS AND IS NOT TO BE USED AS A TOY. THIS PRODUCT IS INTENDED FOR NORMAL OUTDOOR USE; HOWEVER, THE MANUFACTURER RECOMMENDS STORING AND/OR COVERING THIS PRODUCT WHEN ANY FORMIDABLE/SEVERE WEATHER IS APPROACHING.



**WARNING:** DO NOT LOCATE THIS PRODUCT NEAR OPEN FLAMES. DO NOT USE THIS PRODUCT AS A SUPPORT. DO NOT SHAKE, LEAN OR CLIMB ON THE PRODUCT. CHILDREN UNDER THE AGE OF 10, NEAR THE PRODUCT, SHOULD BE SUPERVISED BY A COMPETENT ADULT AT ALL TIMES. THIS PRODUCT IS NOT INTENDED FOR COMMERCIAL USE AND WILL VOID THE WARRANTY.

#### READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

- 1. Close supervision is necessary when this furnishing is used by or near children, or disabled persons, if applicable.
- Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
- Do not move the chaise while it is occupied. Failure to obey this caution could result in injury.
- 4. Do not rock in the chair as you may fall and cause serious injury.



**CAUTION:** When not in use, secure the product in a cool and covered location.



**CAUTION:** Do not locate the product near any heat sources.



**WARNING:** Weight limit for the chair is 250lbs (113.39Kg) for each seat.



**WARNING:** Please keep children out of the assembly area before assembly.



**WARNING:** This chair unit is heavy, and may require two adults for safe assembly.



**WARNING:** Never use this product as a support. Do not shake, lean, or climb on the product at any time.



WARNING: Do not place heavy objects on the chair.

### Warranty

### 2 YEAR FRAME AND 2 YEAR FABRIC LIMITED WARRANTY

#### WHAT IS COVERED

We warrant the frames to be free of manufacturing defects to the original purchaser for two years, and a two year limited warranty for the fabric.

### WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit www.HOMEDEPOT.ca.

### **Pre-assembly**

#### PLANNING ASSEMBLY

Read all instructions before assembly.

To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.



NOTE: More than one person may be required to assemble this product.

# **Pre-assembly (continued)**


### **HARDWARE INCLUDED**



**NOTE:** Hardware not shown to actual size.



Part	Description	Quantity
AA	M6x30 Combination Bolt	4+1
BB	M6x15 Combination Bolt	16+1
CC	Hex Wrench	1



Part	Description	Quantity
Α	Chaise Seat	2
В	Right Arm	2
С	Left Arm	2
D	Chaise Back	2


### **Assembly**

# Connecting The Chaise Seat To The Chaise Right Arm



NOTE: Loosely tighten all bolts using the hex wrench (CC).

- □ Place the right arm (B) upside down on a soft surface.
- □ Attach the chaise seat (A) to the right arm (B)




# **2** Connecting The Chaise Seat To The Chaise Left Arm



NOTE: Loosely tighten all bolts using the hex wrench (CC).

□ Attach the chaise seat (A) to the left arm (C) using M6x15 combination bolts (BB).




### **Assembly (continued)**

# **3** Connecting The Chaise Back To The Chaise Seat




NOTE: Loosely tighten all bolts using the hex wrench (CC).

 Attach the chaise back (D) to the chaise seat (A) using M6x30 combination bolts (AA).



## 4 Checking The Chaise

- Once all of the bolts are in place, fully tighten all the bolts using the hex wrench (CC).
- □ Turn the chaise right side up.
- Ensure all connections are secure before use.



### **Care and Cleaning**

- For best results, clean the frame and fabric with a damp cloth and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- □ Do not clean with abrasive materials, bleach or solvents.
- □ Store the chaise in a dry sheltered place when not in use.
- □ Keep the chaise away from fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.

# HAMPTON BAY

Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

#### 1-855-HD-HAMPTON

#### **HOMEDEPOT.CA**

Retain this manual for future use.

For certification use only
Factory ID #FLS60438