
HAMPTON BAY

USE AND CARE GUIDE

SLATEFORD DINING CHAIR - 2 PK



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. - 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HOMEDEPOT.CA

THANK YOU

Table of Contents

Table of Contents	Pre-Assembly	3
Important Safety Instructions2	Planning Assembly	3
Save These Instructions	Hardware Included	4
Read All Instructions Before Use2	Package Contents	4
Warranty	Assembly	. 5
What is covered	Care and Cleaning	. 7
What is not covered		

Important Safety Instructions

SAVE THESE INSTRUCTIONS



WARNING: THESE CHAIRS ARE MADE FOR THE EXPLICIT PURPOSE OF PROVIDING OUTDOOR FUNCTIONS AND ARE NOT TO BE USED AS A TOY. THIS PRODUCT IS INTENDED FOR NORMAL OUTDOOR USE; HOWEVER, THE MANUFACTURER RECOMMENDS STORING AND/OR COVERING THIS PRODUCT WHEN ANY FORMIDABLE/SEVERE WEATHER IS APPROACHING.



WARNING: DO NOT LOCATE THIS PRODUCT NEAR OPEN FLAMES. DO NOT USE THIS PRODUCT AS A SUPPORT. DO NOT SHAKE, LEAN OR CLIMB ON THE PRODUCT. CHILDREN UNDER THE AGE OF 10, NEAR THE PRODUCT, SHOULD BE SUPERVISED BY A COMPETENT ADULT AT ALL TIMES. THIS PRODUCT IS NOT INTENDED FOR COMMERCIAL USE AND WILL VOID THE WARRANTY.

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

- 1. Close supervision is necessary when this furnishing is used by or near children, or disabled persons, if applicable.
- Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
- 3. Do not move the chair while it is occupied. Failure to obey this caution could result in injury.



CAUTION: When not in use, secure the product in a cool and covered location.



CAUTION: Do not locate the product near any heat sources.



WARNING: Weight limit for the chair is 250lbs (113.39Kg) for each seat.



WARNING: Please keep children out of the assembly area before assembly.



WARNING: This chair unit is heavy, and may require two adults for safe assembly.



WARNING: Never use this product as a support. Do not shake, lean, or climb on the product at any time.



WARNING: Do not place heavy objects on the chair.

Warranty

2 YEAR FRAME AND 2 YEAR FABRIC LIMITED WARRANTY

WHAT IS COVERED

We warrant the frames to be free of manufacturing defects to the original purchaser for two years, and a two year limited warranty for the fabric.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit www.HOMEDEPOT.ca.

Pre-Assembly

PLANNING ASSEMBLY

Read all instructions before assembly.

To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.



NOTE: More than one person may be required to assemble this product.

Pre-Assembly (continued)

HARDWARE INCLUDED




NOTE: Hardware not shown to actual size.



Part	Description	Quantity
AA	M6x15 Combination Bolt	8+1
BB	M6x30 Combination Bolt	8+1
CC	M6x25 Bolt	4+1
DD	Hex Wrench	1

PACKAGE CONTENTS



Part	Description	Quantity
Α	Sling Bucket	2
В	Right Arm	2
С	Left Arm	2
D	Connector Bar	2
E	Support Bar	2

Assembly

Connecting The Sling Bucket, Connector Bar And Support Bar To The Right Arm

Place the right arm (B) on a soft surface.

□ Attach the sling bucket (A) to the right arm (B) using M6x30 combination bolts (BB).


□ Attach the connector bar (D) to the right arm (B) using M6x15 combination bolts (AA).

Insert the support bar (E) to the right arm (B).

Do not tighten all bolts at this step.




NOTE: Loosely tighten all the bolts using the hex wrench (DD).



BB

2 Connecting The Sling Bucket, Connector Bar And Support Bar To The Left Arm

- □ Attach the sling bucket (A) to the left arm (C) using M6x30 combination bolts (BB).
- □ Attach the connector bar (D) to the left arm (C) using M6x15 combination bolts (AA).
- □ Insert the support bar (E) to the left arm (C).
- $\hfill\Box$ Do not tighten all bolts at this step.




HOMEDEPOT.CA

Assembly (continued)


3 Securing The Support Bar

- □ Turn the chair right side up.
- □ Tighten the support bar (E) to the two chair arms (B & C) using M6x25 bolts (CC).
- Do not tighten all bolts at this step.



4 Tightening All Bolts

- Once all of the bolts are in place, fully tighten all the bolts using the hex wrench (DD).
- Ensure all connections are secure before use.



Care and Cleaning

- □ For best results, clean the frame and fabric with a damp cloth and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- □ Do not clean with abrasive materials, bleach or solvents.
- □ Store the chairs in a dry sheltered place when not in use.
- □ Keep the chairs out of fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.

7

HAMPTON BAY

Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HOMEDEPOT.CA

Retain this manual for future use.

For certification use only

Factory Chair ID# FCS60610 RD