
HAMPTON BAY

USE AND CARE GUIDE

ALUMINUM OVERSIZED CHAIR



Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service.

8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HOMEDEPOT.CA

THANK YOU

Table of Contents

Table of Contents	2
Important Safety Instructions	
Save These Instructions	
Read All Instructions Before Use	
Warranty	2
What is Covered	2
What is Not Covered	2

Pre-Assembly	.3
Planning Assembly	. 3
Hardware Included	. 3
Package Contents	. 4
Assembly	.5
Care and Cleaning	

Important Safety Instructions

SAVE THESE INSTRUCTIONS



WARNING: This chair was made for the explicit purpose of providing outdoor functions and is not to be used as a toy.

This product is intended for normal outdoor use; however, the manufacturer recommends storing and / or covering this chair when any formidable / severe weather is approaching.



WARNING: Do not locate this product near open flames. Do not use this product as a support. Do not shake, lean or climb on the product. Children under the age of 10, near the product, should be supervised by a competent adult at all times. This product is NOT intended for commercial use and will void the warranty.

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

- 1. Close supervision is necessary when this product is used by or near children, or disabled persons, if applicable.
- Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
- Do not move the chair while the chair is occupied. Failure to obey this caution could result in injury.
- 4. Do not rock in the chair as you may fall and cause serious injury.
- 5. Please keep children out of the assembly area before assembly.



WARNING: This chair unit is heavy, and may require two adults for safe assembly.



WARNING: Do not place heavy objects on the chair.



WARNING: Weight limit for the chaise is 225lbs(102.06 kg).



CAUTION: When not in use, secure the product in a cool and covered location.



CAUTION: Do not locate the product near any heat source.

Warranty

5 YEAR FRAME AND FABRIC WARRANTY

WHAT IS COVERED

We warrant the frame and fabric to be free of manufacturing defects to the original purchaser for five years.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at 1-855-HD-HAMPTON or visit www.Homedepot.ca.

Pre-Assembly

PLANNING ASSEMBLY

Read all instructions before assembly.

To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.



NOTE: More than one person may be required to assemble this product.

HARDWARE INCLUDED



NOTE: Hardware not shown to actual size.








Part	Description	Quantity
AA	M6x20 combination bolt	24+1
BB	M8x30 combination bolt	12+1
CC	Hex wrench	1

PACKAGE CONTENTS




Part	Description	Quantity
Α	Backrest	2
В	Right arm	2
С	Left arm	2
D	Seat	2
E	Connector bar	4

Assembly


1 ATTACHING THE CONNECTOR BARS TO THE RIGHT ARM

- Place the right arm (B) on the soft surface.
- □ Attached the connector bars (E) to the right arm (B) using M6x20 combination bolts (AA) using the hex wrench (CC)
- Do not fully tighten all the bolts at this step.




2 ATTACHING THE CONNECTOR BAR TO THE LEFT ARM

- □ Attach the connector bars (E) to the left arm (C) using M6x20 combination bolts (AA) using the hex wrench (CC).
- Do not fully tighten all the bolts at this step.




3 CONNECTING THE ARMS TO THE BACKREST

- Attach the left arm (C) to the backrest (A) using M6x20 combination bolts (AA).
- □ Attach the right arm (B) to the backrest (A) using M6x20 combination bolts (AA).
- Do not fully tighten all the bolts at this step.




4 CONNECTING THE SEAT TO THE ARMS

- Turn the chair upside down.
- □ Attach the seat (D) to the left arm (C) and the right arm (B) using M8x30 combination bolts (BB).
- Do not fully tighten all the bolts at this step.



5 CHECKING THE CHAIRS

- Once all of the bolts are in place, fully tighten the bolts using the hex wrench (CC).
- □ Ensure all connections are secure before use.



Care and Cleaning

- For best results, clean the chair with a damp cloth and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- Do not clean with abrasive materials, bleach, or solvents.
- Store the chair in a dry, sheltered place when not in use.
- □ Keep the chair away from fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.

HAMPTON BAY

Questions, problems, missing parts? Before returning to the store, call Hampton Bay Customer Service 8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-855-HD-HAMPTON

HOMEDEPOT.CA

Retain this manual for future use.

For certification use only

Factory Chair ID# FCA60401B